



# UPLIFT DESK<sup>®</sup> Kids Active Stool, 17"

CHR462

Package Contents



Stool



## Step 1

Unbox the stool and recycle cardboard packing materials. Place on a level, dry surface, and sit down to begin use. The Kids Active Stool is a great side seat option that allows children to perch and move more while seated.

## CAUTIONS & WARNINGS

- ⚠ CAUTION:** Read all instructions before use. Failure to use properly may result in damage or personal injury.
- ⚠ WARNING:** This product's maximum weight capacity is 250 lbs. Do not exceed this amount.
- ⚠ CAUTION:** If any component is not in proper working order or appears worn, contact UPLIFT Desk immediately for repair or appropriate replacement parts.
- ⚠ CAUTION:** If you do not understand any part of these warnings, cautions, or instructions, contact UPLIFT Desk for direction in the use of this product.
- ⚠ WARNING:** Always ensure stool is securely positioned during use. For proper balance and stability, always sit on the middle of the seat.
- ⚠ WARNING:** To avoid falling or tipping, keep both feet flat on the ground for balance.
- ⚠ WARNING:** Never stand on the stool.